


METAL GRATE INSTRUCTIONS



Ceramic Disk
Included

Purpose:

The Metal Grate is designed to allow more airflow through to the fire and allows you to get to higher temperatures quicker. Therefore if you grill more often than you smoke low and slow, you will find it more convenient to use a metal grate for achieving those temperatures quicker. If you are cooking low and slow, you may find it convenient to use a ceramic grate.

How to install the Metal Grate:

The grate does have to be used with caution as it does radiate more heat compared to a ceramic grate. Below are instructions on how to properly place and operate the Metal Grate.

IMPORTANT: There is a ceramic disc included with the Metal Grate. This disc is a protective disc to add protection for the base. Place the ceramic disc at the bottom of the base and in the middle of the firebox



The Metal Grate has tapered slots to reduce the changes of bits of charcoal or ash to clog up the airflow. When placing the metal grate in the firebox make sure that the wider tapered slot is towards the bottom of the cooker.